

≡≡ MICROWAVE ≡≡

# Warm 'n Serve™ Dish

Dear Parent,

Thank you for purchasing the Microwave Warm 'n Serve Dish from Playskool Baby. We hope you'll enjoy the convenience of our easy-to-hold carry handle, special tilt-up cover and innovative Scooper® rim. As always, when it comes to the care and growth of your baby, you can expect the very best products from Playskool Baby.



Questions? Call: <sup>TM</sup>  
**1-800-PLAYSKL**

## Here are a few guidelines when using our Warm 'n Serve Dish:

- ALWAYS TEST TEMPERATURE OF FOOD BY TASTING BEFORE FEEDING BABY.
- Always follow food package instructions for warming times.
- Warm 'n Serve Dish is for microwave use only. Do not use in any other type of oven.
- The dish is for warming food only. Do not use for cooking.
- Never leave dish in operating microwave oven for more than 3 minutes.
- Do not warm cooking oil or oily foods in this dish.
- Egg yolks and meat or poultry sticks should not be heated in microwave ovens due to uneven heating and burn hazard caused by splattering.

### **To Use:**

1. Place food into dish and close cover.
2. Locate recommended warming time on baby food jar or package. If not available, consult table on back for warming guidelines.
3. Place dish in microwave oven and heat. Start with shorter warming time and add more time if food needs to be warmer.
4. After warming, grasp handle to remove dish from oven.
5. Stir food with a spoon.
6. ALWAYS TEST TEMPERATURE OF FOOD BY TASTING BEFORE FEEDING BABY.

### **To Clean:**

1. Dispose of any remaining food-- do not save for later use.
2. Remove cover and Scooper® rim to clean. (Note: removing rim is optional.)
3. Dish, cover and Scooper rim are top rack dishwasher safe. If cleaning by hand, use dishcloth and mild detergent. Do not use abrasive powders or scouring pads to clean.

	<b>FULL SIZED MICROWAVE OVENS</b> (Always use 50% power) <b>600-750 watts</b>		<b>COMPACT MICROWAVE OVENS</b> Less than <b>600 watts</b>	
	<b>FULL</b> <b>4 1/2 OZ. JAR</b> <b>(ROOM TEMP.)</b>	<b>HALF-FULL</b> <b>4 1/2 OZ. JAR</b> <b>(REFRIGERATED)</b>	<b>FULL</b> <b>4 1/2 OZ. JAR</b> <b>(ROOM TEMP.)</b>	<b>HALF-FULL</b> <b>4 1/2 OZ. JAR</b> <b>(REFRIGERATED)</b>
<b>Beginner fruits, vegetables, strained foods</b>	<b>15-20 SECONDS</b>	<b>NOT RECOMMENDED</b>	<b>NOT RECOMMENDED</b>	<b>NOT RECOMMENDED</b>
	<b>FULL</b> <b>6 OZ. JAR</b> <b>(ROOM TEMP.)</b>	<b>HALF-FULL</b> <b>6 OZ. JAR</b> <b>(REFRIGERATED)</b>	<b>FULL</b> <b>6 OZ. JAR</b> <b>(ROOM TEMP.)</b>	<b>HALF-FULL</b> <b>6 OZ. JAR</b> <b>(REFRIGERATED)</b>
<b>Strained fruits, vegetables, meats, desserts and jarred cereals</b>	<b>30-40 SECONDS</b>	<b>20-25 SECONDS</b>	<b>25-30 SECONDS</b>	<b>NOT RECOMMENDED</b>
<b>Chunky vegetables and meats</b>	<b>40-50 SECONDS</b>	<b>40-50 SECONDS</b>	<b>25-30 SECONDS</b>	<b>25-30 SECONDS</b>

- Do not use microwave oven to warm less than 3 ounces of baby food.
- Proper warming times vary from oven to oven. Use times on the table as a general guideline only.